

M8 Bolt with spring washer. Through spacer into alternator.

RACETORATIONS



RACEMETTLER

Turn bar to tighten belt and fix with locknuts.

L.H. Locknut.

R.H. Locknut.

5/16" UNC Bolt with spring washer. To pump housing.

4 Cylinder Alternator Fitting Kit

3/8" UNF Bolt with washer.

3/8" to 1/2" UNF adapter. Through engine front plate and bracket.

1/2" Nylock Nut and washer.

