


RACETORATIONS



5/16" UNF Head Bolt
with spring washer. Through
pump housing.




L.H. Locknut.

R.H. Locknut.

Turn bar to tighten belt
and fix with locknuts.

M8 Bolt with spring
washer. Through spacer
into alternator.



6 Cylinder Alternator Fitting Kit

5/16" Nylock Nut
and washer.



Long 5/16" UNF Bolt with washer.
Through spacer, engine front plate
and mounting block.

